

## Directions for using 50mL Dual-Mix Cartridge products

www.useies.com

Insert the plunger, with the track side down, into the slot of the front of the dispenser. Push the metal lever on the back of the dispenser up and slide plunger until it is fully inserted into the dispenser. (Fig. A)




Figure A

Lift up the cartridge lock and allow to fall freely towards the handle. (Fig. B)

Place cartridge into applicator and secure by replacing the cartridge lock to its original position. make sure that it snaps into place. (Fig. C)




Figure B

Remove cap completely from cartridge by turning it counter-clockwise.

(NOTE: Cap can be re-inserted to seal a partially used cartridge. To avoid cross contamination, match up the plugs underneath the cap with its corresponding sides.)

Tilting the gun back, pump the gun until the product flows equally from both chambers. This procedure equalizes the chambers to insure an equal mix. This is a very important step.

Install the static mixer nozzle on the end of the nosepiece and tighten in a clockwise direction until securely fastened.

Pump material through the mixer nozzle. Discard the first 3 inches of product, then proceed with application. To retain unused product, remove the mixer nozzle and install the cap into the appropriate sides of the cartridge after use.




Figure C